

RSMAF-SMAM

RSMA female / SMA male adapter - SMA cable  
adapter for WLAN and GSM

FEATURES

- SMA adapter  
exterior thread + tap  
Inside thread + tap

